



JP1: USE DS87C530 INTERNAL ROM
 JP2: USE EXTERNAL ROM ON HOST
 JP3: ROM SELECT SIGNAL FROM HOST OR Vpp VOLTAGE FROM PROGRAMER

DIP 40 SOCKET MOUNTED ON BOTTOM OF PCB FOR SYSTRONIX P/N 2222 OR EQUIVALENT
 NOTE PIN 1 POSITION
 DIP 40

SYSTRONIX
 555 SOUTH 300 EAST
 SALT LAKE CITY, UT, USA 84111
 TEL: +1-801-534-1017 FAX: -1019
 WWW.SYSTRONIX.COM INFO@SYSTRONIX.COM

Title DS87C530 ADAPTER		
Size	Number	Rev
B		1
Date	Wed Mar 03, 1999	Drawn by
Filename	DS87C530_adapter.SCH	Sheet 1 of 1